

**FRECUENCIAS CENTRALES DE CANALES ASIGNADOS AL SERVICIOS DE
RADIODIFUSIÓN SONORA EN FM**

GRUPO A

GRUPO B

FREC	No. DE CANAL
88.1	1
88.5	2
88.9	3
89.3	4
89.7	5
90.1	6
90.5	7
90.9	8
91.3	9
91.7	10
92.1	11
92.5	12
92.9	13
93.3	14
93.7	15
94.1	16
94.5	17
94.9	18
95.3	19
95.7	20
96.1	21
96.5	22
96.9	23
97.3	24
97.7	25
98.1	26
98.5	27
98.9	28
99.3	29
99.7	30
100.1	31
100.5	32
100.9	33
101.3	34
101.7	35
102.1	36
102.5	37
102.9	38
103.3	39
103.7	40
104.1	41
104.5	42
104.9	43
105.3	44
105.7	45
106.1	46
106.5	47
106.9	48
107.3	49
107.7	50

FREC	No. DE CANAL
88.3	51
88.7	52
89.1	53
89.5	54
89.9	55
90.3	56
90.7	57
91.1	58
91.5	59
91.9	60
92.3	61
92.7	62
93.1	63
93.5	64
93.9	65
94.3	66
94.7	67
95.1	68
95.5	69
95.9	70
96.3	71
96.7	72
97.1	73
97.5	74
97.9	75
98.3	76
98.7	77
99.1	78
99.5	79
99.9	80
100.3	81
100.7	82
101.1	83
101.5	84
101.9	85
102.3	86
102.7	87
103.1	88
103.5	89
103.9	90
104.3	91
104.7	92
105.1	93
105.5	94
105.9	95
106.3	96
106.7	97
107.1	98
107.5	99
107.9	100



NOTA:

- 1 Todas las frecuencias en MHz
- 2 El valor de frecuencia indicado es la frecuencia central del canal
- 3 Un canal tiene 200 kHz de ancho de banda
- 4 Cada grupo de frecuencias se reutilizan en diferentes regiones del país